



I can't hear my phone dialing, but I can still make and receive calls. How do I activate the Dial Pad Tones?

To Reactivate Dial Pad Audible tones (Touch Tone On / Off)

Press **FEATURE** Key

Press **#**

Press **1**