



### How do I set Idle Line Preference on my Comdial DX80?

This feature allows you to access a specific outside line or intercom (ICM) automatically when you lift the handset or press the speakerphone button.

To pickup INTERCOM first upon lifting handset:

- Press **FEATURE** button
- Dial **9 5**
- LCD screen will display:

ICM CO CO-GROUP

- Choose **ICM** option (press button under ICM)
- Press the **SAVE** key, you will hear an audible confirmation and then phone should return to normal

To select first available idle line (Last line is default):

- Press **FEATURE** button
- Dial **9 5**
- LCD screen will display:

ICM CO CO-GROUP

- Choose **CO-GROUP** option (press button under CO-GROUP)
- Dial **9**
- Press the **SAVE** key, you will hear an audible confirmation and then phone should return to normal

To select a specific outside line:

- Press **FEATURE** button
- Dial **9 5**
- LCD screen will display:

ICM CO CO-GROUP

- Choose **CO** option (press button directly under CO)
- "Enter CO Line" input corresponding code to program the Directory Line Number (Code 740–755 = Lines 1–16) EG: To pickup Line 1 input 740, to pickup Line 2 input 741, etc...
- Press the **SAVE** button, you will hear an audible confirmation and then phone should return to normal